

# Radiation test overview for Infrared cooled detectors at LYNRED


Samuel Ducret

CNES – COMET • Infrared detection for space applications Workshop • 7<sup>th</sup> – 9<sup>th</sup> June 2023

# Agenda

- 1) Context and problematic of the radiation test on cooled IR Lynred detectors
- 2) Single Events Effect on the cooled IR Lynred detectors
- 3) Cumulated effects :
  - 1) TID
  - 2) TNID
- 4) Conclusions

# Introduction



## Detection circuit (MCT):

- TNID
- TID

## ROIC (silicon):

- TID
- SEE

- ❑ For space application, we have to test 3 kind of radiations effect on our IR detector:
  - SEE
  - TID
  - TNID
- ❑ Specificity of our product is the cryogenic temperature


## Constraints to performed radiation test on cooled IR detectors:

- ☐ **Cryogenic temperature [45 K ; 200 K]**
  - Manage dewar, cryo cooler, chiller, vaccum, on the radiation site
  - A lot of material => logistical aspect not to neglect:
    - More than 1000 kg of equipment
    - Up to more than 20 transport crates
  - Time: all, take more time at cryogenic Temp !
  - Risk of damage the DUT (freeze ...)
- ☐ **Limited number of sample available**
- ☐ **Time measurements on radiation site**
- ☐ **Limited radiation data available at cryogenic temperature**
- ☐ **Radiation standards not always fully applicable on our products**




## SEE radiation test, baseline

- ❑ SEE test done at ROIC level as soon as possible
- ❑ SEE radiation test performed with:
  - Heavy ions (baseline)
  - Proton (if necessary)
- ❑ Different kind of event are possible on Lynred detectors:
  - SEU
  - SET
  - SEFI
  - SEL
- ❑ Baseline SEE conditions test
  - Cryogenic temperature (baseline = mission temperature)
  - Polarization according specifications and standards
- ❑ A Specific test bench is developed for each project/product
  - Monitoring and recording of events in real time





## Example of a SEE test bench for heavy ions irradiation (1/2)



- DUT with :
- electronics boards
  - Power supply
  - delatcheur

Cryogenic temperature Management and monitoring

SEE test bench management and monitoring


infrared detection for space applications workshop, Toulouse 7th-9th, June 2023

## Example of a SEE test bench for heavy ions irradiation (2/2)

DUT

cryostat

Cryo Cooler



Ions beam

## SEL sensitivity:

### ❑ One destructive event on our detector : SEL

- Specific design rules applied at Lynred
- R&D focus on this event, with onera lab


*See IEEE TNS Vol 66, n°7, pp.1510-1515, 2019*

### ❑ No SEL detected at room and Cryogenic Temperature, with our last ROIC technology and design:

- No SEL detected on full ROIC at cryogenic temperature
- No SEL detected up to 100°C and LET = 62 MeV.cm<sup>2</sup>/mg

### ❑ Experimental & simulation study done to find the SEL threshold


- Submitted to RADECS 2023





## Impact of cryogenic temperature on SEU, SET, SEFI

- ❑ R&T studies (simulations and experimental test) have been done on the effect of radiation cryogenic temperature on SEU, SET, SEFI
- ❑ Experimental SEE data at different radiation T on:
  - flip flop test chip
  - Full ROIC
- ❑ Very limited impact of cryogenic temperatures on the occurrence of SET, SEU and SEFI
- ❑ Different publications on the subject: See “*MDPI, sensors 2018, 18, 2338*” for a synthesize of these results



## TID and TNID : E/O measurements on radiation site

- ☐ **E/O measurements done on radiation site (on IRFPA)**
  - Dark current
  - Power Consumption
  - ROIC noise
  - RTS noise
- ☐ **Specific test bench with DVR and black body**
- ☐ **Specific test bench for specific test vehicle:**
  - $I=f(V)$  for photodiodes
  - $V_{th}$ , leakage currents for MOS transistors
- ☐ **Measurements done at cryogenic temperature**
- ☐ **Need to keep the cryogenic temperature all along the radiation steps and the measurements steps. Without temperature variation.**



## TID / TNID radiation test: baseline conditions

### ❑ TID & TNID test done on:

- The full IRFPA
- Samples representative of FM (same lot)


### ❑ Baseline TID radiation conditions test

- TID tests are done with gamma ray at cryogenic temperature (baseline = mission temperature)
- Polarization ON during irradiation
- Dose rate in Window 1 ("Standard Rate") of ESCC22900 radiation standard
  - No dose rate effect on the ROIC technology


### ❑ Baseline TNID radiation conditions test

- TNID tests are done mainly with proton at cryogenic temperature
- Polarization OFF during irradiation

#### TID test





#### TNID test



# TID degradation driven by ROIC

- ❑ TID performance limited by the ROIC part





## Lynred radiation methodology summary

- ❑ **Investigate radiation effect as soon as possible for a given space project:**
  - Choice of the good level of design hardening versus mission needs
  - Radiation test
- ❑ **First: radiation test performed at test vehicles level:**
  - Radiation levels above the typical level requested for IR space product
  - Assess the different technologies and design radiation performance
  - Investigate the Temperature and polarization effect
  - Adjust the qualification test plan and improve our irradiation degradation knowledge
- ❑ **Second: radiation test performed on IRFPA:**
  - On IRFPA fully representative of FM for qualification
  - Radiation level according mission profile (minimum margin = x2)
  - Tests done at cryogenic temperature (mission temperature)

## Conclusions

- ☐ **Our detector is sensitive to 3 kind of radiation effect :**
  - SEE
  - TID
  - TNID
- ☐ **For qualification, we have to perform 3 different kind of radiation test at cryogenic temperature**
- ☐ **Performing radiation test at cryogenic temperature is quite difficult and challenging**
- ☐ **Lynred detectors are compliant with customers radiation specifications**
  - More than 20 space project qualified for space application
  - 50 FM in flight
- ☐ **Improved capacity and “know how” to perform radiation test at cryogenic temperature**
  - Specific test bench and dedicated equipment
  - Development of collaboration on the radiation thematic (R&D studies)

LYNRED

THANK YOU  
FOR YOUR ATTENTION


CONFIDENTIAL



WWW.LYNRED.COM




WWW.LYNRED.COM



*"All rights reserved.  
Contents are LYNRED' property  
and can be changed by LYNRED  
at any time.*

*The information contained herein  
is confidential and intended  
solely for the person to which it  
is addressed.*

*Any copy or dissemination of the  
information contained herein is  
prohibited."*



**WWW.LYNRED.COM**

info@lynred.com

This document and any related information are LYNRED property (subject to the rights of any third parties). Its distribution is not a transfer of property. It contains confidential information and can only be transmitted to authorized people within the company. Communication to third parties is allowed provided a non-disclosure agreement has been agreed between parties. Unless prior written authorization from author, any other use is strictly forbidden and subject to legal proceedings. LYNRED shall not be liable for any consequence resulting from the use or inability to use information contained herein.